



NOTE:
 INSTALL 6" ATLAS VENT SPACER STRIPS ON BOTH SIDES OF VALLEY CENTER LINE AS SHOWN FOR OSB SUPPORT.
 FASTEN THROUGH EACH SPACER STRIP INTO STRUCTURAL DECK USING ATLAS NAIL BASE FASTENERS.
 CONTACT ATLAS SALES OFFICE FOR ADDITIONAL VENT SPACER STRIPS.