



ISOMETRIC VIEW

NOTE:

NAIL BASE INSULATION SHALL BE TRIMMED BACK FROM RAKE EDGE AND EAVE TO ACCOMODATE RAKE AND EAVE NAILERS. OSB SHALL BE SUPPORTED ON RAKE EDGE AND EAVE BY WOOD NAILER.